

THE
RABBIT
COMPANY™

OVERVIEW

All products by The Rabbit Company™ are made from soft, smooth, body safe materials.

Our easy to use interface allows users to easily find the right stimulation and intensity. Get ready for sensual satisfaction that can not be matched and will have you craving for more.

The Lay-On Rabbit™



External Stimulators

Control / LED Indicator

DC Charging Port









GETTING STARTED


1. Before first use, charge your rabbit for approximately 2 hours. The USB charging cable can be plugged into any USB port or USB/AC power adapter (Not included).

- Flashing Light = Charging
- Solid Light = Fully Charged
- Rapid Flashing Light = Low battery, charge is needed






2. Wash your rabbit with soap and water, or toy cleaner suitable for use with silicone items.




3. Lubricate your rabbit (if needed) with a water based, silicone compatible lubricant.
4. Turn ON your rabbit by pressing 
5. To change the vibration intensity, press and release  and 
6. To change the vibration pattern, press and release 
7. Press the  button again to off.



CONTROLLING YOUR RABBIT

- To turn the item ON press 
- Press and release  to increase vibration intensity
- Press and release  to decrease vibration intensity
- To change the vibration pattern, press and release 
- Press the  button again to off.




CHARGING

- Insert the charging plug in the designated charging area
- Flashing light indicates item is charging
- Solid light indicates item is fully charged
- Rabbits require approximately **2** hours for full charge




Flashing Light = Charging



Solid Light = Fully Charged

TRAVEL LOCK

- All rabbit items include travel lock for safe and convenient travel
- While the rabbit is powered OFF, simultaneously press and hold the **+** and **-** buttons for 3 seconds. Flashing light will indicate the item is locked.
- To unlock simply press and hold the **+** and **-** again for 3 seconds. Flashing light will indicate lock is disabled.



VIBRATING MODES

1. Constant



2. Wave



3. Pulse




VIBRATING MODES


4. Ascend



5. Oscillate



6. Random



1. Always clean your Rabbit thoroughly before and after each use.


2. We recommend using a premium water-based lubricant when needed. Silicone-based lubricants are not recommended and can cause damage to the product. Never use hand cream, or massage oils as lubricants for your intimate areas.

3. To properly clean your rabbit, use a suitable silicone-compatible toy cleanser. If this is not available, wash the silicone area of your rabbit with luke-warm water and an antibacterial soap. Rinse clean and



pat dry using a lint-free cloth or towel.
Do not use cleaners containing alcohol,
petrol or acetone.

4. Avoid leaving your rabbit in direct
sunlight and never expose it to extreme
heat.



5. Waterproof function: The rabbit is
not intended for extended or excessive
submersion. After use in the bath or
the shower, make sure to completely
and thoroughly dry before storage.
For best product performance, limit
bathtub use to 15 minutes. Excessive
or prolonged underwater exposure
can lead to damage or failure of the
product.



SPECIFICATIONS

Materials Body Safe ABS / Silicone

Size 104 x 50 x 32.5 mm

Weight 80 g

Battery Li-ion 320 mAh

Charging 2 hours

Use Time 2 hours

Max Noise Level <68 db

Interface 4 button interface
6 modes

DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):

The crossed-out dustbin symbol indicates that these items should not be treated as household waste, but rather brought to the appropriate collection point for recycling electrical and electronic equipment.



RoHS



Complete user instructions in
additional languages can be
found at:

www.TheRabbitCompany.com

Designed and Developed by
The Rabbit Company™

Made in China
© The Rabbit Company™

TheRabbitCompany.com