



## USER GUIDE


### GETTING STARTED

1. Before first use, charge your device for approximately 120 minutes. The USB charging cable can be plugged into any USB port or USB / AC power adapter (not included).

- **Charging = LED Light Flashing**
- **Charged = LED Light Solid**



2. Wash your device with soap and water, or toy cleaner suitable for use with silicone items.




4. Our products are designed to be splash-proof. Your device can be used in the shower and can be run under water in the sink to be cleaned. **Never immerse your rabbit in water.**

### TRAVEL LOCK


#### APPLICABLE TO

- Realistic Rabbit Vibrator with Throbbing Shaft
- Pearls Rabbit Vibrator with Rotating Shaft
- Beads Rabbit Vibrator with Rotating Shaft
- G-Spot Rabbit Vibrator with Rotating Shaft
- Thrusting Rabbit Vibrator with Throbbing Shaft
- G-Spot Thrusting Rabbit Vibrator with Throbbing Shaft
- Double-Penetration Rabbit Vibrator with Rotating Shaft
- Come Hither Rabbit Vibrator with Throbbing Shaft
- Suction Rabbit Vibrator with Throbbing Shaft



To enable the travel lock, press and hold both the **+ -** buttons for 3 seconds while the device is off. The LED-indicator will flash twice indicating that the device is locked.

To disable the travel lock, press and hold both the **+ -** buttons for 3 seconds. The LED-indicator will flash twice indicating that the device is now unlocked and ready for use.



#### APPLICABLE TO

- Slim Shaft Rabbit Vibrator with Rotating Beads
- Slim Realistic Double-Penetration Rabbit Vibrator with Rotating Beads
- Thrusting Slim Shaft Rabbit Vibrator with Thrusting Function


To enable the travel lock, press and hold the **⏻** buttons for 3 seconds while the device is off. The LED-indicator will flash twice indicating that the device is locked.

To disable the travel lock, press and hold the **⏻** buttons for 3 seconds. The LED-indicator will flash twice indicating that the device is now unlocked and ready for use.

### CONTROLS

#### APPLICABLE TO:

- Realistic Rabbit Vibrator with Throbbing Shaft
- Pearls Rabbit Vibrator with Rotating Shaft
- Beads Rabbit Vibrator with Rotating Shaft
- G-Spot Rabbit Vibrator with Rotating Shaft
- Double-Penetration Rabbit Vibrator with Rotating Shaft



#### 1. 3 Rotation Speeds

Increase or decrease rotation speeds with a single touch


#### 2. Rotation Direction

One button system to toggle between rotation directions

**3. 7 Rabbit Vibration Patterns**  
Cycle through 7 unique vibration patterns in the rabbit for the ultimate experience

#### APPLICABLE TO:

- Thrusting Rabbit Vibrator with Throbbing Shaft
- G-Spot Thrusting Rabbit Vibrator with Throbbing Shaft



#### 1. 3 Thrust Speeds

Increase or decrease thrust speeds with a single touch


#### 2. Thrust ON/OFF

One button system to toggle between thrusting or non-thrusting

**3. 10 Rabbit Vibration Patterns**  
Cycle through 10 unique vibration patterns in the rabbit for the ultimate experience

#### APPLICABLE TO:

- Come Hither Rabbit Vibrator with Throbbing Shaft



#### 1. 3 Come Hither Speeds

Increase or decrease come hither with a single touch


#### 2. Come Hither ON/OFF

One button system to toggle between Come Hither or non-Come Hither

**3. 7 Rabbit Vibration Patterns**  
Cycle through 7 unique vibration patterns in the rabbit for the ultimate experience

#### APPLICABLE TO:

- Suction Rabbit Vibrator with Throbbing Shaft



#### 1. 3 Vibration Speeds

Increase or decrease vibration speeds with a single touch


#### 2. 6 Vibration Patterns

One button system to toggle between vibration patterns of the shaft

**3. 6 Rabbit Suction Modes**  
Cycle through 6 suction modes in the rabbit for the ultimate experience

#### APPLICABLE TO:

- Slim Shaft Rabbit Vibrator with Rotating Beads
- Slim Realistic Double-Penetration Rabbit Vibrator with Rotating Beads



#### 1. 3 Rotation Speeds

Increase or decrease rotation speeds with a single touch


**2. 7 Rabbit Vibration Patterns**  
Cycle through 7 unique vibration patterns in the rabbit for the ultimate experience

#### 3. Power ON/OFF

Start using your Rabbit with the one-touch power button

#### APPLICABLE TO:

- Thrusting Slim Shaft Rabbit Vibrator with Thrusting Function



#### 1. 3 Thrust Speeds

Increase or decrease thrust speeds with a single touch

**2. 7 Rabbit Vibration Patterns**  
Cycle through 7 unique vibration patterns in the rabbit for the ultimate experience

#### 3. Power ON/OFF

Start using your Rabbit with the one-touch power button

### SPECIFICATIONS

#### Usage Time, Battery Type & Measurements

##### • Realistic Rabbit Vibrator with Throbbing Shaft

Up to 100 minutes of usage time (1635 / 750mAh / 3.7V Lithium Battery)  
45mm x 258mm x 82mm

##### • Pearls Rabbit Vibrator with Rotating Shaft

Up to 70 minutes of usage time (1635 / 750mAh / 3.7V Lithium Battery)  
45mm x 260mm x 84mm

##### • Beads Rabbit Vibrator with Rotating Shaft

Up to 120 minutes of usage time (1635 / 750mAh / 3.7V Lithium Battery)  
45mm x 260mm x 84mm

##### • G-Spot Rabbit Vibrator with Rotating Shaft

Up to 100 minutes of usage time (1635 / 750mAh / 3.7V Lithium Battery)  
45mm x 262mm x 82mm

##### • Double-Penetration Rabbit Vibrator with Rotating Shaft

Up to 110 minutes of usage time (1635 / 750mAh / 3.7V Lithium Battery)  
45mm x 261mm x 110mm

##### • Slim Shaft Rabbit Vibrator with Rotating Beads

Up to 100 minutes of usage time (1635 / 750mAh / 3.7V Lithium Battery)  
37mm x 217mm x 68mm

##### • Slim Realistic Double-Penetration Rabbit Vibrator with Rotating Beads

Up to 90 minutes of usage time (1635 / 750mAh / 3.7V Lithium Battery)  
37mm x 223mm x 94mm

##### • Thrusting Rabbit Vibrator with Throbbing Shaft

Up to 100 minutes of usage time (1635 / 750mAh / 3.7V Lithium Battery)  
45mm x 254mm x 79mm

##### • G-Spot Thrusting Rabbit Vibrator with Throbbing Shaft

Up to 150 minutes of usage time (1635 / 750mAh / 3.7V Lithium Battery)  
45mm x 250mm x 79mm

##### • Come Hither Rabbit Vibrator with Throbbing Shaft

Up to 120 minutes of usage time (1635 / 750mAh / 3.7V Lithium Battery)  
45mm x 250mm x 79mm

##### • Suction Rabbit Vibrator with Throbbing Shaft

Up to 150 minutes of usage time (1635 / 750mAh / 3.7V Lithium Battery)  
45mm x 250mm x 79mm

##### • Thrusting Slim Shaft Rabbit Vibrator with Thrusting Function

Up to 90 minutes of usage time (1635 / 750mAh / 3.7V Lithium Battery)  
37mm x 226mm x 68mm

#### Charging Time

120 minutes

#### Materials

Body Safe ABS / Silicone

### WARRANTY INFORMATION

Rabbit Essentials provides a 5-year warranty from the purchase date on the purchase receipt. This warranty is supplementary to the warranty rights in the state of purchase. The warranty covers the function of the product. It does not include external damages due to normal wear or accident-related damage, misuse or negligence. The warranty does not apply in the event of failure to observe the operating or assembly instructions. Any battery pack included in the delivery is explicitly excluded from the warranty. The validity of the warranty expires in case of improper use or tampering.

Open to everyone who has purchased a Rabbit Essentials personal massager, if you find your product is faulty outside the warranty period, or you have lost your proof of purchase you can claim on this warranty. You will then be entitled to a 50% discount on [www.rabbitesentials.com](http://www.rabbitesentials.com) for the purchase of a new device, limited for one-time use only.

To enforce the warranty claim, please return any problematic items still under warranty with the original purchase receipt to [cs@rabbitesentials.com](mailto:cs@rabbitesentials.com) for a return authorization.

### DISPOSAL INFORMATION

Disposal of old electronic equipment (applicable in the EU and other European countries with separate waste collection systems):



The crossed-out dustbin symbol indicates that these items should not be treated as household waste, but rather brought to the appropriate collection point for recycling electrical and electronic equipment.



Points de collecte sur [www.quefairedemesdechets.fr](http://www.quefairedemesdechets.fr)

For other user guides in multiple languages please visit:  
[www.rabbitesentials.com](http://www.rabbitesentials.com)

Email us at [cs@rabbitesentials.com](mailto:cs@rabbitesentials.com) for any unanswered questions